


MIDI Module Interface SO-02-001 Rev F Headers Pinout – Serdashop.com

J5: Board Voltage Header



J11: Line in header







J10: Line out header




J9: Volume Attenuation Left Side

J8: Volume Attenuation Right Side

Volume selection jumper positions for J8 and J9 :



J1: MIDI IN header



J6: MIDI THRU




Buffered repeated MIDI IN signal

J7: MIDI OUT



Some modules might support midi out for patch dump, etc..

NOTE:
MIDI THRU/OUT
Connection to
Female midi
Connector:



SW1: Optional reset button